

Installation Guidelines

Accessories

HD2 Stair Edging

Data Sheet: (sheet 1 of 1) 28/02/08

1. It should be ensured that all surfaces to which the profile is to be fixed are dry, flat and free from any contaminants.
2. Cut the profile to the size required.
3. Place the profile in position and mark the position of the screw holes onto the substrate.
4. Drill the substrate to a depth of 30 -35mm and insert suitable fixing plugs into the holes.
5. Apply high performance cartridge adhesive with gap filling properties (e.g. Gripfill) to the back of the profile and place onto the substrate. Ensure that all of the profile is in contact with the substrate and there is a minimum 80% coverage of adhesive on the underside of the profile. Please refer to adhesive manufacturers data sheets for application details.
6. Using 6mm or 8mm screws (dependent on profile) fix through the profile, into the plugs and tighten.

Note.

The profile should be installed directly onto the substrate and **NOT** on top of any floorcovering. The floorcovering should be abutted up to the back edge of the profile.

If any further information is required, please do not hesitate to contact Gradus Technical Services on (+44)1625 428922 or fax on (+44)1625 425226