



- Polyflor Bevel Line PU incorporates a polyurethane surface treatment, which protects the floorcovering by resisting soiling and scuffing. This protection facilitates a reduction in the intensity of the construction clean and provides the foundation for the ongoing maintenance regime. This easier cleanability offers maintenance cost savings when compared with non-treated materials.
- The following maintenance instructions are designed to minimise the cost factor, without compromising the long-term appearance of your floorcovering.

**INITIAL CONSTRUCTION CLEAN**

- Remove all loose debris.
- Ensure that all traces of adhesive are removed from the surface of the floorcovering.
- Mop sweep or vacuum to remove dust and grit.
- Damp mop with a neutral detergent.
- If required, dry buff with a 1000 rpm plus rotary machine fitted with a suitable clean pad.

**ROUTINE MAINTENANCE**

- The following recommendations are provided as a guideline, and the frequencies can be changed to optimise the appearance.

DAILY

- Mop sweep or vacuum to remove dust and loose dirt.
- If required, spot clean to remove stubborn marks with a neutral cleanser.
- If required, dry buff to restore finish.

WEEKLY/MONTHLY

- Assess the appearance of the floor.
- If required, scrub with a scrubber dryer fitted with suitable pads, and using neutral cleanser (pH 7 to 9).
- If required, dry buff to restore finish.

**APPLICATION OF A FLOOR DRESSING**

- The polyurethane surface treatment will provide an initial protection to the floorcovering. However an application of a metalised polish may be required eventually to provide extra protection. The level and intensity of traffic and soiling will determine how soon the polish will have to be applied. For polish free maintenance see the Polyflor PUR range of products. For polish application please follow details of the procedure below.
- Using an applicator and tray, or Kentucky mop with wringer and bucket, the first coat should be applied thinly and evenly across the floor, to within 200mm of the skirtings. It should then be left to dry. This normally takes approximately thirty minutes, depending on the ambient conditions and the thickness of the coating.
- When the first coat is dry, a second coat should be applied at right angles to the direction of the first. Subsequent coats should be applied at right angles, and the final coat should be applied right up to the skirting.
- Two to three thin coats are usually sufficient to provide excellent resistance to abrasion, scuffing and removal of black heel marking. However, be guided by your own periodic assessments for the particular location.
- In order to minimise costs, subsequent polish applications may be applied only to traffic paths.
- Periodically - generally every six months - assess the appearance of the floor. If there is an unacceptable build-up of polish, this should be stripped and reapplied, as per the instructions above.



NOTE: The maintenance regime requires the installation of an effective barrier matting system.

- Cleaners and detergents should be diluted as per the manufacturers' instructions.
- These maintenance instructions are intended for Polyflor Bevel Line PU, which incorporates a polyurethane surface treatment. For other Polyflor products, reference should be made to their specific floorcare sheets.
- For further information and advice on specific applications, consult Polyflor Customer Technical Services on +44 (0)161 767 1912, or email tech@polyflor.com.
- Always follow the Health and Safety guidance provided.
- At the date of issue the data presented is correct. However, Polyflor Ltd. reserve the right to make changes which do not adversely affect performance or quality.

REGULAR CLEANING IS MORE BENEFICIAL TO THE FLOORCOVERING AND MORE COST-EFFECTIVE THAN OCCASIONAL HEAVY CLEANING.

POLYFLOR LTD. PO BOX 3 RADCLIFFE NEW ROAD WHITEFIELD MANCHESTER M45 7NR UK
 TEL: +44 (0)161 767 1111 UK SALES DIRECT: +44 (0)161 767 1122 UK FAX: +44 (0)161 767 1128
 EXPORT FAX: +44 (0)161 767 1166 E-MAIL: INFO@POLYFLOR.COM WWW.POLYFLOR.COM
 UK SAMPLE REQUESTS: +44 (0)161 767 2551

James Halstead
 FLOORING



2006

POLYFLOR

BEVELline™
 THE PROJECT COLLECTION



FLOORCARE

POLYFLOR™
 COVERING THE WORLD