



- The following maintenance instructions are designed to minimise the cost factor, without compromising the long-term appearance of your floorcovering.
- Once the installation is complete, do not traffic for 24 hours until the adhesive has dried.

**INITIAL CONSTRUCTION CLEAN**

- Remove all loose debris.
- Ensure that all traces of adhesive are removed from the surface of the floorcovering.
- Mop sweep or vacuum to remove dust and grit.
- Damp mop with a neutral detergent.

**APPLICATION OF A FLOOR DRESSING**

- Ensure there is a good key between the floor dressing and the surface of the flooring, scrubbing the floor if required.
- Using an applicator and tray, or Kentucky mop with wringer and bucket, the first coat should be applied thinly and evenly across the floor, to within 200mm of the skirtings. It should then be left to dry. This normally takes approximately thirty minutes, depending on the ambient conditions and the thickness of the coating.
- When the first coat is dry, a second coat should be applied at right angles to the direction of the first. Subsequent coats should be applied at right angles, and the final coat should be applied right up to the skirting.
- Two to three thin coats are usually sufficient to provide excellent resistance to abrasion, scuffing and removal of black heel marking. However, be guided by your own periodic assessments for the particular location.
- In order to minimise costs, subsequent polish applications may be applied only to traffic paths.
- Periodically - generally every six months - assess the appearance of the floor. If there is an unacceptable build-up of polish, this should be stripped and reapplied, as per the instructions above.

**ROUTINE MAINTENANCE**

- The following recommendations are provided as a guideline, and the frequencies can be changed to optimise the appearance.
- Mop sweep or vacuum to remove dust and loose dirt.
- Assess the appearance of the floor.
- As required, scrub with a neutral cleanser diluted as per the manufacturers recommendations; a 3M Doodlebug or deck scrubber can be used.
- If a lustre is required then the floor should be damp mopped with a dilution of maintainer, which should then be left to dry before being trafficked.



NOTE: The maintenance regime requires the installation of an effective barrier matting system.

- Cleaners and detergents should be diluted as per the manufacturers' instructions. These maintenance instructions are intended for Polyflor Colonia Homeline. For other Polyflor products, reference should be made to their specific floorcare sheets.
- For further guidance, contact Polyflor Customer Technical Support. Always follow the Health and Safety guidance provided.
- At the date of issue the data presented is correct. However, Polyflor Ltd. reserve the right to make changes which do not adversely affect performance or quality.

REGULAR CLEANING IS MORE BENEFICIAL TO THE FLOORCOVERING AND MORE COST-EFFECTIVE THAN OCCASIONAL HEAVY CLEANING.

POLYFLOR

Colonia

HOMELINE COLLECTION

FLOORCARE